

SOLDER PASTE DISPENSING IN PCB **ASSEMBLY**

by Timothy O'Neill Originally published in PCEA

While stencil printing has long been the cornerstone of applying solder paste, it faces limitations with extremely small or large components. This challenge underscores the need for adaptable and innovative solder paste application methods. In this article, we delve into the realm of advanced dispensing technologies, exploring solutions that can help overcome common production challenges.

Solder Paste Application Challenges

Stencil printing, despite its efficiency, struggles with the dual extremes of component sizes—area array and bottom termination components continue to shrink, while connectors and other components may increase in size. This variance stretches the capabilities of stencil printing. Dispensing offers the advantage of infinite flexibility, capable of producing both minuscule and substantial deposits while seamlessly integrating into the existing SMT process.




FIGURE 1. 25-guage needle dispensing Type 6 solder paste.

For example, a 25-gauge dispensing needle has an inner diameter of 10mils, or 0.25mm and a length of 0.25" or 6.35mm. If we were to treat that tip as a stencil aperture and calculate its area ratio, it would be 0.10, which is considered impossible on a stencil by a factor of five! Without the pressure of the dispenser and finer solder particles in the paste, nothing would get deposited onto the PCB. Figure 1 shows a typical 25-gauge needle producing a 15mil, or 0.375mm deposit with Type 6 solder paste.

Overview of Dispensing Techniques

Dispensing technology encompasses several methods, each with its unique advantages and limitations. Table 1 summarizes the advantages and disadvantages of three main classes of dispensing equipment used for solder paste deposition.

Dispenser Type	Advantages	Disadvantages
Timed Pulsed Pneumatic	Low Cost More repeatable than manual application Low maintenance	May damage paste Limitations to dot size
Positive Displacement	Smaller dot size Excellent repeatability Flexible	High cost Increased maintenance Increased cycle time
Jetting	Non-contact Smallest dot size Fastest cycle time Excellent repeatability Flexible	High cost New technology Costly materials

TABLE 1. Dispensing equipment types.

Despite the apparent benefits, dispensing's primary drawback is its cycle time, significantly slower compared



to the thousands of deposits a squeegee can achieve in one stroke during stencil printing. However, when substrate or component configuration and solder paste volume requirements do not allow for stencil printing, dispensing solder paste may be the best option, either by itself or in addition to printing. Some stencil printer models even have internal paste (and adhesive) dispensers as an option, as seen in Figure 2.



FIGURE 2. Solder paste dispenser mounted inside stencil printer.

Optimizing Dispensing for Efficiency and Quality

Achieving success with dispensing technologies requires careful consideration of equipment selection and process adjustments. The solder paste being dispensed consists of two primary ingredients: solder alloy powder and flux medium. Because solder and flux densities are so different, keeping the suspension homogenous during dispensing is challenging.

Additionally, solder powder is particulate material, which increases the probability that dispensers will occasionally clog. To avoid separation or clogging with timed pulse pneumatic and positive displacement dispensers, several key guidelines should be carefully followed:

- Use the shortest tip length possible.
- Keep air pressure as low as possible; <40psi (2.75bar) for timed pulse dispensing and for <10psi (0.7 bar) positive displacement, and do not cycle the air pressure on/off.
- Control the Z-axis height relative to the substrate, this is critical for dot-to-dot size repeatability and reproducibility.
- Store solder paste under refrigeration, tip down, before use. If warmed to ambient temperature, do not re-refrigerate.
- Once paste has begun clogging the dispense tip, it should be scrapped.

Modifications in powder mesh size and metal content may also be necessary as the dispensing tip's inner diameter decreases, necessitating collaboration with material suppliers to ensure compatibility and performance.



FIGURE 3. Jet dispenser on SPI system touches up insufficient paste deposits and then re-inspects to assure proper volume.

Strategic Considerations for Dispensing Success

When it comes to solder paste deposition, stencil printing is almost always the first choice because it is the industry standard. Material availability and a vast resource and knowledge base within the technical community also make printing the preferred option. But when printing alone cannot supply small enough or large enough amounts of solder paste, dispensing is often the answer.

Critical to the success of dispensing methods is the collaboration between assemblers, material suppliers, and equipment manufacturers. Understanding the inherent properties of solder paste and the technical nuances of dispensing equipment can significantly impact the efficiency and quality of PCB assembly processes.